

@AIRBUS

A319

A320

A321

**NORMAL
CHECKLIST**

CONFIGURATION SAFETY CHECK

Bat check req'd only if ext/apu power not established
(Bats must have been at rest for at least 6 hours)

BAT SWITCHES (2) OFF

BAT VOLTAGE (2) CK > 25V

BAT SWITCHES (2) AUTO

DOME LT (if req'd) BRT

LDG GR LEVER DOWN

ENG MASTER SWS (2) OFF

ENG MODE SEL NORM

SPEEDBRAKE RET

FLAP LEVER POS'N CHECK

If Ext Pwr avail:

EXT PWR SW PUSH



CONFIGURATION SAFETY CHECK

(CONTINUED)

If Ext Pwr not avail:

APU FIRE TEST ACCOMPLISH
APU MASTER SW ON
APU START SW ON
COCKPIT LTS AS RORD

After EXT/APU power established:

DU'S (.....) ON
APU BLEED SW OFF
VENT PANEL LTS EXTINGUISHED
PROBE/W-HEAT SW AUTO
NAV & LOGO LTS 1 OR 2
WING LT AS REQ'D
FLAPS (ECAM) AGREEMENT
PARK BRAKE SET
MAINTENANCE LOG CHECK

A319/320/321

PRELIM COCKPIT CHECK

ADIRS	ALIGN
REAR C/B PANELS	CHECK
LIBRARY (RH)	CHECK
GEAR PINS & COVERS	CHECK
EMERG EQUIPMENT	CHECK
RAIN REPELLENT	CHECK
PBE	CHECK
LIBRARY BREFCASE	STOWED
HALON EXT	CHECK
LIBRARY (RH)	CHECK
FLASHLIGHTS (2)	CHECK
OVERHEAD C/B PANEL	CHECK
AUDIO SWITCHING SEL	NORM
50VU PANEL	ALL LTS EXTING
PA	CHECK

BEFORE START CHECK

COCKPIT PREP COMPLETE (BOTH)

GEAR PINS and COVERS REMOVED

SIGNS ON/AUTO

ADIRS NAV

FUEL QTY _____ LB/KG, CHECKED

T/O DATA & V BUGS _____ SET (BOTH)

BARO REF _____ SET (BOTH)

WINDOWS DOORS CLOSED (BOTH)

BEACON ON

THR LEVERS IDLE

PARK BRAKE AS RQRD

** BEFORE START CHECK COMPLETE **

AFTER START CHECK

ANTI ICE AS RQRD
ECAM STATUS CHECKED
PITCH TRIM SET
RUDDER TRIM ZERO

** AFTER START CHECK COMPLETE **

BEFORE TAKEOFF CHECK

FLIGHT CONTROLS CHECKED (BOTH)
FLT INST CHECKED (BOTH)
BRIEFING CONFIRMED
FLAP SETTING CONF ____ (BOTH)
V1, VR, V2/FLX TEMP (BOTH)
TRANSPONDER AUTO/SET
ECAM T/O MEMO NO BLUE
AUTO BRK MAX
SIGNS ON
CIRCUIT READY
SPLRS ARMED
FLAPS T/O
T/O CONFIG NORM

CABIN CREW ADVISED
ENG MODE SEL AS RQRD
PACKS AS RQRD

** BEFORE T/O CHECK COMPLETE **

A319/320/321